

Well Flow Management

Fluids Sampling and Analysis

Transfer Unit

The Expro Transfer Unit is designed to be used with all types of Wireline Formation Testers (RDT, MDT, RCI, etc.).

Prior to transfer from WFT sample chambers, the samples are heated up to 80 °C to dissolve any wax components, and then pressurised back into single phase.

As a standard procedure, the samples are kept in the automated rocking bench for 4 hours before commencing the transfer.

Features and benefits

- Automated agitation for reconditioning of dual phase samples
- Up to 6 WFT sample chambers can be restored at one time
- Mercury free
- No hot spots



Agitation/heating bench

Specifications

Pressure max	1000 barg
Temperature max	100 °C
